

User's Manual

ALAN PRORADIO FM



ALAN Electronics GmbH
Daimlerstraße 1k
D- 63303 Dreieich

Index

Drawing of the Radio.....	3
Introduction.....	4
Active-Function / FM-Radio.....	4
Coverage.....	4
Expected battery operating timing	4
Battery Charging	4
Cleaning.....	4
Safety precautions.....	4
Icons on LCD	5
Power Save	5
Key Function.....	6
ON/OFF & Shift.....	6
Function.....	6
UP/DOWN & Volume Control	6
PTT (Push To Talk)	6
Way Call Ringer(CALL)	6
Key Lock.....	6
Sub Option Selection Mode.....	7
Call Ringer Melody Selection Mode.....	7
Beep Tone Selection Mode	7
Roger Beep Selection Mode.....	7
Channel List.....	7
Basic Channel Selection.....	8
CTCSS (Code Tone Controlled Squelch System)	8
CTCSS Frequency List.....	8
VOX Selection Mode.....	9
VOX Recovery Time Selection Mode.....	9
Active Function	10
Channel Scan Mode.....	10
Normal Scan Mode	10
Priority Scan Mode.....	10
Stopwatch Mode	10
FM-Radio Mode	11
CE – Declaration of Conformity	11
Technical Specifications	12
Notes about European Warranty	13
If something doesn't work.....	13

Drawing of the radio



- 1 Antenna
- 2 LCD-Panel
- 3 UP Button & Volume Control
- 4 DOWN Button & Volume Control
- 5 Ein-Aus und Shift-Taste (Auswahltaste)
- 6 Function Button)
- 7 Built-in microphone (Active)
- 8 Flexboom microphone



- 9 Charger / PTT-socket
- 10 Push-To-Talk (PTT)
- 11 Active ON/OFF – Volume control

Introduction

Proradio keeps the advantages of a heavy duty, rigid headset, to ensure the safety of hearing in noisy working environments, combined with the functions of a modern PMR-transceiver, that can be used without licence in nearly all European countries (see country list attached).

Active function

Active hearing-protection with electronically Level-Limiting at 83 dB.

With the black rotary-switch on the side of the shell you turn on the active function. Now you can hear the surrounding-noises and speak again stereophonically. At abrupt rising noise (hammer-blow, shot etc.) the electronic will limit the level which you hear in the headset

FM-Radio

You can receive the FM Radio (87.5 – 108 MHz)

Coverage

The operating band (446MHz) allows clear communication, virtually free from atmospheric interferences and – despite the low power – will allow you to communicate up to a distance of 2 to 5 km. The maximum range is obtained operating in a open space.

If you find communication is not possible, many times this can be solved by moving a few meters to a new location. Range is also reduces while operating in a vehicle or metal building.

Expected Battery Operating Timing

The typical life time of one battery charging cycle assumes that in standard applications during 90 % of the operating time the radio is in standby mode, and transmit and receiving periods with higher volume are only 10 % of the total time.

In this mode the battery charging will last for about 24 hours max.

An automatic energy saving system will be enabled when the radio does not receive any incoming signal within the last minute of operation.

With enabled broadcast radio or “active mode” the energy saving system will not be enabled, thus the maximum operating time may go down to appr. 8 hours, depending on the volume selected.

Battery Charging

Use the supplied original charger only. The charger is adjusted specially to the batteries of the unit. Different charger may destroy the battery irreversible

To increase the life of your battery, avoid charging it longer than necessary. Subsequently 12 hours will provide a full charge. Too often overloading effectively reduces the battery capacity after some time.

Cleaning


Hanger, headset and microphone may be cleaned several times with a damp cloth only.

Do not use alcohol or harsh chemicals !

Safety precautions

- never expose the unit to extreme temperatures or dust
- avoid contact with water
- use the supplied original charger only
- to increase the lifetime of your battery, avoid charging it longer than necessary.

ICONS on LCD



RSSI

(Receiving Signal Strength Indicator) or TX Bar Icon Indicates the receiving signal strength during transmission and it can be indicated the number of bar according to the strength of receiving signal.



Auto Channel Scan Indicator

Appears in the normal scan mode or when the normal scan mode is activated



Priority Scan Indicator

Appears in priority scan mode or when the priority scan mode is activated.



Key Lock Indicator

Blinks in auto lock selection mode or when the key lock is activated.



Vox Indicator

Blinks in VOX selection mode or appears when VOX is activated.



Battery Level Indicator

Battery Level Meter indicates the remaining battery strength.



Power Save

Proradio is supplied with an automatic power saving circuit. If the transceiver receives no signal for longer about 1 minute the „Power Save Function“ automatically will be activated. Power save is reducing at minimum the consumption extending the Standby-time. The Display shows „SAVE“. When **Proradio** is reduced to a minimum power consumption nevertheless you can receive signals without restriction- it will switch on immediately after receiving the first signal.



TX Indicator

Appears when a signal is being transmitted.



RX Indicator

Appears when a signal is being received.




CTCSS Indicator

Blinks when the correct CTCSS tone is entered.



Large Segment Display

Indicates the channel number in use at the normal mode. When the Function Button is pressed, it Displays the function menu in sequence:



Ch / rdo / Sc / Uo / H00 / Sub / CAL / bEP / rog / tAL / [1] / [2] / [3] / P1 / P2 / P3 / P4 / P5

Small Segment Display Displays the FM frequency at the FM mode. Displays the SUBMENU of each MENU in the function mode.

Key Function

Power ON/OFF & Shift Button

Press this button briefly to turn the unit on. A short confirming melody will play. A momentary press of this button is not effected to any function in the Function edit mode and stand-by mode except in the specific mode.



When FM radio is on - Pressing this button allows you to shift to next preset FM radio Broadcasting.

Press this button for longer than 1.5 seconds to turn the unit off.

A momentary press of this button is also used to shift to the other small segment display during the function edit mode and reset the stopwatch counter in the stopwatch mode.

Function Button

Short Touch - Press this button briefly to enter function edit mode in standby mode.

Long Touch - Press for longer than 1.5 seconds to activate the KEY LOCK in the standby mode.



Up Button

Short Touch - In the standby mode, press this button briefly to move to the next higher main volume level.

In the function edit mode, press briefly to shift from the current option in each submenu to the next option in the same submenu.

Long Touch - Pressing this button for more than 1.5 seconds will allow you to navigate at a more rapid rate through different volume level in the standby mode or through different menus in the function edit mode.



Down Button

Short Touch - In the standby mode, press this button briefly to move to the previous lower main volume level. In the function edit mode, press briefly to shift from the current option in each submenu to the previous option in the same submenu.

Long Touch - Pressing this button for more than 1.5 seconds will allow you to navigate at a more rapid rate through different volume level in the standby mode or through different menus in the function edit



Push To Talk (PTT) Button

Press it firmly and speak into the Microphone to transmit. The red Tx LED Indicator at the right side of the LCD Panel will light. Release it to revert to standby mode.

When an incoming call is received, the green Rx LED Indicator on the left side of the LCD Panel will light.

Way Call Ringer

Press the **PTT** Button twice quickly to call another party on the same channel and pressing the button once during and pressing the button once during a calling stops the calling and then returns to the standby mode. The user selected call ringer melody will play.

Key Lock

Press the **Function** Button for longer than 1.5 seconds to activate the KEY LOCK in the standby mode

NOTE :Please note all buttons will be disabled except the PTT Button will remain fully operational.

Setting and Operation

Sub Option Selection Mode

This mode allows you to enter the sub option selection mode.-Press the **Function** Button until the word “**Sub**” appears in the LCD. You can now select between “**yes**” or “**No**”.

-If you press the **Function** Button when “yes” blinks on the CD Panel, you enter into the Sub

Function edit menu.

- Pressing the **Function** Button when, “no” blinks, returns to standby.Access to following SUB Menu points is only possible when You have avtivated the SUB menu by setting to “Yes”.

Call ringer melody selection mode

This feature provides 7 user selectable call ringer melodies to alert you of a calling party.

To select your favorite Call Ringer melody,In the Sub option selection mode, press the **Function** Button when the “yes” blinks.

Press the **Down** Button or **Up** Button to preview the seven available melodies.

Press the **PTT** Button to confirm your selection.



Beep Tone Selection Mode

This feature allows you to program beeping or not beeping with key selection.

If the Key beep off is chosen no beep sound when you press the button The call signal, power on/off beep and roger beep make a sound regardless of the beep.

Press the **Function** Button from the Call selection mode.

Press the **Up** Button or **Down** Button to select from on or off.

Press the **PTT** Button to confirm your selection and return to standby mode.

When you press **Enter** button or do not press any key within 5 seconds, it returns back to stand-by.



Roger Beep Selection Mode

If Roger Beep option is on, when you finish the transmitting automatically the **ProRadio** will produce a beep sound and transmit a sub-code tone to the partner.

To access the Roger Selection Mode :

Press the **Function** Button from the Key beep selection mode.

Press the **Up** Button or Down Button to select from Roger on or off.

Press the **PTT** Button to confirm your selection and return to standby mode.



Channel	Frequency (MHz)
1	446.00625
2	446.01875
3	446.03125
4	446.04375
5	446.05625

6	446.06875
7	446.08125
8	446.09375

Basic Channel Selection

In order to communicate with other PMR units, both you and the receiving party must be on the same channel.

Proradio has 8 channels (1-8) as indicated by the large digits in the LCD Display Panel. Before, trying to transmit on the selected channel, you should press the **PTT** Button to check the activity on that channel. If someone is already on the selected channel, you should try another channel that is clear. To change the basic channel, In the standby mode, press the Up Button briefly to move to the next higher main channel number. Press the **Down** Button briefly to move to the next lower main channel number.

CTCSS (Coded Tone Controlled Squelch System)

This feature allows you to utilize a subaudio coding channel system (subaudio codes 00-38) within a main channel. This enables you to communicate with another party on the same main channel without becoming disturbed by listening to other conversations on the same channel.

This helps to avoid congestion on the main channel and filters out unwanted noise and static. There are 38 CTCSS sub-channels for each main channel.

To change the CTCSS sub-channel, press the **Function Button** until the word “Ch” appears in the LCD Panel.

Press the **Shift** Button and the two small number on the right side will blink on the LCD Panel. Press the **Down** Button or the **Up** Button to choose the desired sub-channel to use. The corresponding sub-code frequency will be displayed in the lower right corner. Press the **PTT** Button to confirm your selection and return to standby mode.

NOTE: To communicate with other PMR units, they must be switched to the same channel and CTCSS sub-code.

To communicate with other PMR units that do not have sub-codes, switch your unit to the same channel with the sub-code set to OFF.

CTCSS Frequency List

SUB Channel	Tone Frequency		SUB Channel	Tone Frequency
1	67,0 Hz		20	131,8 Hz
2	71,9 Hz		21	136,5 Hz
3	74,4 Hz		22	141,3 Hz
4	77,0 Hz		23	146,2 Hz
5	79,7 Hz		24	151,4 Hz
6	82,5 Hz		25	156,7 Hz
7	85,4 Hz		26	162,2 Hz
8	88,5 Hz		27	167,9 Hz
9	91,5 Hz		28	173,8 Hz
10	94,8 Hz		29	179,9 Hz
11	97,4 Hz		30	186,2 Hz
12	100,0 Hz		31	192,8 Hz
13	103,5 Hz		32	203,5 Hz
14	107,2 Hz		33	210,7 Hz
15	110,9 Hz		34	218,1 Hz
16	114,8 Hz		35	225,7 Hz

17	118,8 Hz		36	233,6 Hz
18	123,0 Hz		37	241,8 Hz
19	127,3 Hz		38	250,3 Hz

VOX & VOX Recovery Time Selection Mode

1) VOX Selection Mode

The Voice Activated Transmission (VOX) function allows your voice to activate transmission automatically when the **ProRadio** is used within not too noisy environments.

It also allows Handsfree use , if You should not have the hands free for pressing PTT knob.

To access the VOX Selection menu,

Press the **Function** Button until the word “**UO**” appears in the LCD Panel.

Press the **Down** Button or the **Up** Button to select from **Hi, nr, Lo or OFF**.

The High, normal or low setting determines VOX response sensitivity.

Press the **PTT** Button to confirm your selection.

To turn off the VOX feature, enter the VOX selection mode and then select **OFF**.

VOX Recovery Time Selection Mode

This allows the response characteristics of the VOX function to be precisely adjusted to suit individual needs.

To access the VOX Recovery Time Selection menu,

Press the **Function** Button until the word “**UO**” appears in the LCD Panel.

Press the **Power/Shift** Button to confirm your selection and switch to **VOX recovery time** selection.

Press the **Down** Button or the **Up** Button to select from **5, 3, 2 or 1 second** setting.

This setting determines the delay time between transmitting and receiving.

Press the **PTT** Button to confirm your selection.

Please note you may need to try different VOX time settings to determine the best value to suit your speaking habit.

Stufe 1	1 Sekunde
Stufe 2	2 Sekunden
Stufe 3	3 Sekunden
Stufe 4	5 Sekunden

NOTE. *Vox mode is deactivated as long as the FM broadcast radio is in use.*

We do not recommend to use the VOX function in noisy environments- the voice switching circuit may detect surrounding sound as voice and may transmit unwanted audio .

Active Function

Active hearing-protection with electronically Level-Limiting at 83 dB. Suitable for impulse-noise. With the black rotary-switch on the side of the shell you turn on the active mode function. Now you can hear the surrounding-noises and speak again stereophonically. At abrupt rising noise (hammer-blow, shot etc.) the electronic will limit the level which you hear in the headset.

Channel Scan Mode

Normal Scan Mode

This feature allows you to scan for an active channel and communicate with the party transmitting.

The power saver is disabled in this mode. To access the Auto Channel Scan menu,

Press the **Function** Button until the word "SC" appears in the LCD.

Press the **Down** Button or the **Up** Button to choose "nr".

Press the **Monitor** Button to confirm your selection.

The unit will begin scanning for an active main channel. If a transmission is detected, the Rx and RSSI icons will appear in the LCD Panel.

To turn off the auto channel scan feature return to the Scan mode by pressing the **Function** Button and choose "OFF".

You can pause on any channel while in the Auto Channel Scan Mode by pressing the **PTT** Button during the reception of a signal for 5 seconds afterward.

Priority Scan Mode

This feature allows you to monitor two different channels at the same time.

If you pre-set any priority channel other than the current channel in use, the pre-set channel will be scanned every 0.5 second and signals you when a call is received.

While in the Priority Channel Scan Mode you may hear transmission from either a primary or secondary channel when transmitting.

The unit will always transmit on the primary channel unless the **PTT** Button is pressed during or immediately following the reception of secondary channel transmission.

The power saver mode is disabled in the Priority channel scan mode and the volume is not adjustable.

To access the Priority channel scan mode.

Press the **Function** Button until the word "SC" appears in the LCD Panel.

Press the **Up** Button or the **Down** Button to choose "Pr" and then press the **Shift** Button.

Choose the priority channel by pressing **Up** Button and **Down** Button to select the desired channel number you wish to closely monitor.

Press the **PTT** Button to confirm your selection.

To turn off the Priority channel scan feature, press the **Function** Button until the word "SC" appears on the LCD Panel and then choose "OFF" in the scan mode.

Stopwatch Mode

In this mode you can use the stopwatch to time.

To access the Stopwatch mode :

Press the **Function** Button until the word "H00" appears on the LCD Panel.

Press the **Up** Button to **start** and **stop** the counter up while the stopwatch is running, pressing the **Down** Button allows you to obtain the **lap time**.

Press the **Power/Enter** Button to **reset** the stopwatch time.

Press the **Function** Button to **turn off** the stopwatch function.

FM Radio Mode

FM Only: You can receive the FM Radio only

FM plus: You can receive the FRS signal even while you listen to the FM Radio.

When the FM only or FM plus is selected on the FM selection mode, FM icon() appears on LCD Panel.

And you can choose the channel by pressing the Up Button and the Down Button.

When the FM only or FM plus is selected on the FM selection, you can select the way of channel selection in seek scan and tune scan by pressing the Enter Button.

If you select seek scan, you can select the FM radio channel by carrier detect way and if you select tune scan you can select the FM radio channel

CE- Declaration of Conformity

This unit complies to all relevant European Standards and Regulations for PMR 446 radio service. This radio may be used in many EU countries and some other states applying the R&TTE directive of the European Community. However, there are still some restrictions to use PMR 446 in following countries:



Italy : PMR 446 is allowed, but still requests an operating licence for regular use. Exception: short time use for travellers in Italy.

Belgium: No restrictions for travellers using the radio in Belgium free of charge and licence for less than 3 months. **Residents of Belgium** must apply for a radio operating licence according to Belgian regulations.

Ireland: CTCSS signalling (subcodes 01-38) must be switched on for use in Ireland.

Eastern Europe: Please ask the local authorities before using the radio, because only few of the new EU member states apply already the european R&TTE directive. Following countries still apply special national approval regulations, not (yet) valid for PMR 446 radio:

Poland, Estonia, Letavia, Lithuania, Ukraine, Russia, Belarus, Slowenia and some others.

This unit fully complies to the following European standards:

Radio& Spectrum engineering:

EN 300 296-2 (2001), EN 55013 +A12, 13, 14 (1990-99) (FM radio part 87.5-108 MHz)

Electromagnetic Compatibility (EMC): EN 301 489-0 and EN 301 489-5 (2000),

Electrical safety: EN 60 065.

The unit is intended to be used in following european (EU and non EU countries):

A, B, CH and FL, D, DK, E, F, FIN, GB, GR, H, I, IS, IR, L, N, NL, P, S

Because the European regulations are in a steady update process, we recommend that You download our latest issue of the Declaration of Conformity from our internet server (e.g. <http://www.alan-albrecht.de>)

Technical specifications

Frequency Range	446.00625 - 446.09375 MHz
FM-Radio	87.5 - 108 MHz
No. of Channels	8 in 12.5KHz
Frequency tolerance	+/- 5 ppm (-10°C - +55°C)
TX-Mode	F3E
Antenna	Integrated, semi-rigid rubber antenna
Battery	4x battery NIMH 1.2 v Mignon
Output power	Max. 0.5 Watt (ERP)
Modulation capability	+/- 2.5 KHz max.
Harmonics & Spurious	Tx : -36 dBm. Rx : -57 dBm
Receiver sensitivity	0.5 μ V EMF (50 Ω) /20 dB SINAD
Receiver- Audio Output	1.2 VRMS= ca. 180 mV at 8 Ω
Consumption Save	25/15 mA
Consumption RX	100 mA (vol. max.)
Consumption TX	250-300 mA
R&TTE, CE conformity	notified according to European R&TTE directive in all countries allowing the PMR446 radio service. Latest country lists will be published on our service-website.
Coverage	Max. 2/5 km (open space)
Operating time	More than 24 hours (5% tx) More than 15 hours (20% tx)
Charging time	Max. 12 hours
Weight	569 g

European 2 years warranty

The distributor, dealer or retail shop warrants to the original retail purchaser of this product that should this product or any part of it, under normal use and conditions, be proven defective in material or workmanship within 2 years from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), to the distributor, dealer or his authorized repair center.

The Company disclaims liability for communications range of this product. The warranty does not apply to any product or part thereof which, in the opinion of the company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). The warranty does not apply to accessory parts or problems caused through not authorized or not recommended accessories like batteries, external power supplies and over voltage caused through external power supplies, light bulbs, broken antennas, broken swivel belt clips, broken or damaged acrylic glass windows and cabinet parts. Rechargeable batteries have a limited life time because of physical reasons, it is normal and must be accepted that such batteries reduce their capacity steadily when frequently charged and discharged; these batteries are not covered by the 2 years European warranty regulation.

In case of malfunctions please contact the dealer or person where you have purchased your radio.

If something doesn't work ...

It's impossible to connect the partner station:

Did you turn on the unit ?

Did you adjust the right volume level ?

Did you select the same channel like your partner station ?

Aktiv mode doesn't work:

Did you turn on the Active function ?

Did you adjust the right volume level?

It's impossible to turn off the unit:

Connect the **Proradio** to the charger. If now **Proradio** can be turned on, the batteries are probably only discharged. Turn off **Proradio** again and wait, until the batteries are fully charged.

If You should have any other problem, please ask Your distributor for further help.

You will find our full documentation, incl. the latest issues of Declarations of Conformity, as well as service hints etc. anytime on our download server

<http://service.alan-germany.de/PMR446>