SCHEMATIC

GE Superbase 3-5875A CB

RV:3
RV:201
T 209
L 212
L 213
L 214

set RV 202
Down for
Rf Meter Scale.
On SSB. Set for
MAX



NOTE: Service Manual with Parts List may be obtained for $3.00 by using the ACCESSORY ORDER FORM (specify model number), or write to: General Electric Co., P.O. Box 831, Utica, New York 13501.

Bi-Comm Electronics
(South Africa)